

SCHEMA DI MONTAGGIO/assembling scheme









MOBILI LOCKERS

lockers cabinets



ART.190-191

CODICE code	777 700 841
DISEGNO drawing	SM 52052
DATA date	16-07-2018
PAGINA page	1/2

**ART.190****ART.191**

CODE	COLOUR	CODE	COLOUR	CODE	COLOUR	CODE	Ø x L	CODE	Ø x L	COLOUR	CODE	Ø	COLOUR	CODE	COLOUR	CODE	Ø x L x L2	COLOUR
504315005	NERO black	505182201	FERRO iron	505132317	GRIGIO	505060902	8 x 30 5/16" x 1 3/16"	505041903	7,5 x 36 5/16" x 1 3/8" - Zinc Plated	ZINCATO	505031911	14 9/16"	ZINCATA zinc plated	506072219	ZINCATA Zinc Plated	505041920	7 x 9 x 7,5 1/4" x 5/16" x 3/8" - zinc plated	ZINCATO
	x 4		x 1		x 4		x 16		x 12			x 12			x 12		x 4	






**N.B. PER IL MONTAGGIO
SEGUIRE LE FASI NUMERATE**
assemble following the numbered phases



**FASI / phases 1-2-3-4-5-6**

SEGUE
assembling in the following page




FA5I / phases 7-8-9-10-11-12-13-14

CODE	COLOUR	CODE	COLOUR	CODE	COLOUR	CODE	COLOUR	CODE	Ø x L	COLOUR
505031920	NICKEL	507051019	NICKEL	507062319	NICKEL	404400409	ARGENTO	506940309	3,5 x 15	ZINCATO
	nickel		nickel		nickel		silver		1/8" x 9/16"	Zinc Plated
	N x4		O x2		P x2		S x1		T1 x2	



REGOLAZIONE ANTE / adjusting doors

14



Montaggio ante
Assembling doors


13



- 13a** Posizionare la parte anteriore della cerniera nella parte anteriore della basetta.
Place the rear part of the hinge on the front side of the mounting plate.
- 13b** Far scivolare la cerniera sulla basetta fino all'arresto.
Let the hinge slide on the mounting plate until it stops.
- 13c** Fissare la vite di connessione.
Tighten the connecting screw.

CUSCINI (OPTIONAL)
cushions (OPTIONAL)

ART.081



ART.082

